

SmokeTip

Battery Maintenance Instructions

Depending on your smoking habits, the battery may not function as it did when you received it. There are several solutions:

Cleaning

A clogged battery may not charge or function properly. Below are simple steps to clean.

There are two “air vent holes” located at the base (end that screws into the cartridge) that can become clogged. Simply take a sewing needle or similar thin item and clear out any debris.



On the inside of the base, take a q-tip dipped in rubbing alcohol (isopropyl) and clean the inside of the charging base.



Clearing & Resetting

Under normal conditions debris should not clog the battery, but sometimes pocket lint or dust can cause the battery to malfunction. To try and fix this issue BLOW and DRAW from the TOP of the battery and from the BASE of the battery several times. You will not feel a strong suction when do you this, but this can help reset the battery.

If the above does not work, please send the battery back for replacement.

SmokeTip
PO Box 26332
Collegeville, PA 19426